




## ME6X 5-Slot Cradle Quick Start Guide



Front




Back



### Instruction Manual



#### 1. ME6X Charging:

Connect the 24V/5A charger to the DC port on the back of the ME6X 5-Slot Cradle. Once connected, the MEFERI logo light will illuminate. Then, insert the ME6X device into the Cradle slot; the device is now charging. While charging, the status indicator on the device will turn red, and it will turn green when fully charged.



## 2. ME6X Charging with Protective Boot:

Connect the charger to the DC port on the ME6X 5-Slot Cradle. Once connected, the MEFERI logo light will illuminate. Then, remove the U-shaped trim from the charging slot to expand the compartment, and insert the ME6X with Protective Boot into the cradle slot. The ME6X will now enter the charging state. The status indicator on the device will display red while charging and turn green when fully charged.



## 3. Battery Charging:

Connect the charger to the DC port of the ME6X 5-Slot Cradle. Once connected, the MEFERI logo light will illuminate. Insert the battery into the additional box on the top of the cradle, ensuring that the battery and charger contact connectors are properly aligned. The battery will now enter the charging state. During the charging process, the indicator light will show red and turn green when the battery is fully charged. The battery can be charged independently or simultaneously with the ME6X device.